## RECTANGULAR DOME LIGHT INSTRUCTION MANUAL



To properly install this light, you must have a good understanding of automotive electrical procedures and systems, along with proficiency in the installation of lighting equipment.



## INSTALLATION

- Remove corner covers (A) to expose screw holes. Make a note of which cover goes on which corner.
- 2. Mark screw [3] locations on surface. Pre-drill or otherwise prepare holes as required.
- 3. Mark wire location and drill hole. Make connections and test light operation.
- 4. Install screws 🕒
- 5. Re-install corner covers. Note\* there are two sets of different cover geometries.
  Be sure to orient properly using corresponding locations from step 1.

